



# HAYNES

## AUTOMOTIVE TECHNICAL DATABOOK

HELP

### VOLKSWAGEN

|                  |         |
|------------------|---------|
| Passat 1.6       | 88 - 93 |
| Passat 1.6i      | 94 - 96 |
| Passat 1.6i      | 95 - 96 |
| Passat 1.6i      | 97      |
| Passat 1.6i      | 97      |
| Passat 1.6i CAT  | 88 - 90 |
| Passat 1.8 & CAT | 88 - 91 |
| Passat 1.8 Turbo | 97      |
| Passat 1.8i      | 93 - 94 |
| Passat 1.8i      | 93 - 96 |
| Passat 1.8i      | 94 - 97 |
| Passat 1.8i      | 97      |
| Passat 1.8i CAT  | 88 - 90 |
| Passat 1.8i CAT  | 90 - 91 |
| Passat 1.8i CAT  | 91 - 93 |
| Passat 1.8i CAT  | 91 - 93 |
| Passat 16V       | 88 - 92 |

|                        |         |
|------------------------|---------|
| Passat 16V CAT         | 88 - 93 |
| Passat 2.0 & Syncro    | 94 - 96 |
| Passat 2.0 CAT         | 93 - 95 |
| Passat 2.0i            | 95 - 97 |
| Passat 2.0i & 4x4 CAT  | 90 - 94 |
| Passat 2.2             | 85 - 88 |
| Passat 2.3 VR5         | 97      |
| Passat 2.8 DOHC 30V    | 97      |
| Passat 2.8 VR6         | 93 - 96 |
| Passat 2.9 Syncro      | 94 - 96 |
| Passat GT              | 88 - 90 |
| Passat VR6             | 91 - 93 |
| Passat/Santana 1.6     | 83 - 88 |
| Passat/Santana 1.8     | 83 - 88 |
| Passat/Santana 1.8 CAT | 84 - 88 |
| Passat/Santana 2.0     | 83 - 88 |